

TAY 650

No.	Class of TOOL Version	NAME
1	1012394	REDUCTION GEARBOX
2	GU25497/1	EXTRACTION & LIFTING TOOL
3	GU27727	LIFT EXE
4	GU27814	ASSEMBLY TOOL
5	GU27816	LIFTING TOOL
6	GU27840	LIFTING TOOL
7	GU28102/1	LIFTING TOOL
8	GU28140	BUILD STAND
9	GU28150	LIFTING & INSP. Beam
10	GU28182	CLOCKING PIN
11	GU28276	DOGGING TOOL
12	GU28439	EXTRACTION TOOL
13	GU29272	LIFTING TOOL
14	GU29287	BUILD STAND
15	GU29728	DOGGING PLATE
16	GU29738	INSPECTION BRIDGE - MEASURING BEAM
17	GU30228	DOGGING BEAM
18	GU30978	CLOCKING PIN
19	HU10288	CLOCK HOLDER
20	HU13623	SOCKET ADAPTOR
21	HU13626	SOCKET END
22	HU13735	IMMOBILIZER PLATE
23	HU13736	SOCKET ADAPTOR
24	HU17140	BLANKING POT
25	HU7662	DOGGING RING
26	HU7735	RETAINING NUT
27	HU8258	INSPECTION STAND
28	HU8793	EXTRACTOR

29	GU23043	build stand
30	GU27755	EXTRACTOR
31	GU27756	LIFTING TOOL
32	GU27759	EXTRACTOR
33	GU27788	EXTRACTOR
34	GU28898	LIFTING TOOL
35	HU3118	MEASURE TOWER
36	HU3162	SCREWED CAP
37	HU6815	HU6815
38	HU7483	TURBINE ROTOR
39	HU12763	ANCHOR PLATE
40	HU12814	ARRGT
41	HU13259	ENGINE ELECTION
42	HU13539-2	VARIOS
43	HU13543-2	NUT PACK
44	HU13545	ENGINE ELECTION
45	HU13546	ENGINE ELECTION
46	H13563	DIFFUSER CASING ENGINE
47	HU13590	ROTOR DISCS AND SHAFT
48	H13591	ROTOR DISCS AND SHAFT
49	H13593	NUT RETAINING
50	HU13608	SOCKET COUPLING
51	H13702	ARRT TURBINE ROTOR
52	H13864	DIFFUSER CASING ENGINE
53	H17565	DRIVING ADAPTOR
54	CP4579	BASIC UNIT ASSY FRAME
55	HU2395	Lifting Tool
56	HU2354/1	Build Stand
57	GU24766	Adapter
58	HU29631	Dogging Sleeve
59	HU3744	Extractor
60	HU7025/1	Adaptor
61	HU3746	Adaptor

62	GU23925	Adapter
63	HU6998/1	Location plug and ram adapter
64	HU3950	Retaining plug
65	GU23706	Hydraulic extractor
66	ERE1001	Enerpac pump
67	GU24647	Extraction segments
68	GU29153	Extraction segments
69	GU24648	Extraction segments
70	GU23913	Extraction segments
71	GU25506	Extractor
72	HU2408	Protective sleeve
73	HU2407	Extractor
74	HU8531	Extractor
75	HU5687	Distance piece
76	GU23052	Reaction bar
77	HU17194/1	Build stand
78	HU23860	Location collar
79	HU16669	Adjustable support ring
80	HU5459	Support ring
81	GU19789	Tool Adapter
82	HU16674	Pressing adapter
83	HU16684	Assembling tower
84	HU16685	Assembling tower
85	HU16675	Assembling tower
86	GU29510	Adapter
87	HU16698/1	Adapter
88	HU24577	Adapter
89	HU24576	Adapter
90	HU24575	Adapter
91	HU24574	Adapter
92	HU16683	Assembling tower
93	HU1489	Adapter
94	GU23056	Hydraulic assembly tool

95	GU21325/1	Spacer selection gauge
96	GU27648	Setting piece
97	HU2370	Distance ring
98	HU16686	Assembly tower
99	GU24766	ADAPTOR
100	GU25506	STRACTOR & CLAMPING TOOL
101	GU23598	Retaining ring
102	GU24641	LOCATING RING
103	GU24647	extraction segments
104	GU29153	extraction segments
105	GU23913	extraction segments

